

Convenience Light Switches

MAKE/MODEL	MODEL YEAR	LOCATION
AUDI		
Audi 100	1977-1988	Hood
Audi 200	1980-1988	Hood
CHRYSLER LLC		
All Dodge, Chrysler, Jeep, Plymouth, Eagle	1998 & before	Hood & Trunk
FORD MOTOR COMPANY		
Ford Mustang	2000 & before	Hood & Trunk
Ford Crown Victoria	2000 & before	Hood & Trunk
Mercury Grand Marquis	2000 & before	Hood & Trunk
Lincoln Town Car	2000 & before	Hood & Trunk
Ford, Lincoln, Mercury, and Merkur cars	1996 & before	Hood & Trunk
Ford, Lincoln, and Mercury trucks, SUVs, and vans	2001 & before	Hood
<i>*Excludes: 1999 and newer model year Ford Econoline, Windstar, Ranger, and Mercury Villager</i>		
Mazda Navajo	1993-1997	Hood
Mazda B-Series Pick-up	1995-1999	Hood
<i>*Ranger/B-Series phased out of mercury switches with 1999 model year</i>		
Volvo hood and trunk switches	1991 & before	Hood & Trunk
Volvo vanity mirror switches <i>Excludes Volvo 240</i>	1986-1991	Vanity Mirror
<i>*Volvo convenience switches may contain glass mercury capsules. Use care when removing convenience switches from these vehicles.</i>		
GENERAL MOTORS		
All Chevrolet, GMC, Cadillac, Buick, Oldsmobile, Pontiac, Saturn, Saab	1999 & before	Hood & Trunk
<i>*Excludes: 1999 model year Chevrolet Astro, Silverado, GMC Safari, and Sierra</i>		
Cadillac Escalade	2000	Hood
Chevrolet Blazer	2000–2002	Hood
Chevrolet Cavalier	2000, 2001	Trunk
Chevrolet Corvette	2000	Hood
Chevrolet Express	2000–2002	Hood
Chevrolet S-10 Crew cab	2002	Hood
GMC Denali	2000	Hood
GMC Envoy	2000, 2001	Hood
GMC Jimmy	2000, 2001	Hood
GMC Savana	2000-2002	Hood
GMC Sonoma Crew cab	2002	Hood
Luxury G-Van	2001, 2002	Hood
Oldsmobile Bravada	2000-2002	Hood
Pontiac Sunfire	2000, 2001	Trunk
PORSCHE		
924	1976-1985	Hood
924 S	1986-1988	Hood
944	1982-1988	Hood
944 S	1987-1988	Hood
944 S2	1989-1991	Hood
944 Turbo	1986-1991	Hood
928	1978-1983	Hood
928 S	1980-1983	Hood
928 S/S4	1984-1990	Hood
BMW, MITSUBISHI, NISSAN, SUBARU, TOYOTA, and VOLKSWAGEN vehicles do not contain mercury switches.		

ABS G-Force Sensors

MAKE/MODEL	MODEL YEAR	LOCATION
AUDI		
Audi 80/90	1987–1993	Rear Seat
Audi 100/Avant	1987–1993	Rear Seat
Audi V8	1989–1995	Rear Seat
Audi 200	1987–1991	Rear Seat
Audi Coupe Quattro	1987–1992	Rear Seat
CHRYSLER LLC		
4WD Dodge Stealth	1992–1996	Rear Center
Jeep Cherokee	1992–2001	Rear Seat
Jeep Grand Cherokee	1993–2001	Rear Seat
Jeep Wrangler	1992–2003	Driver Seat
FORD MOTOR COMPANY		
Ford Bronco	1993–1997	Driver Seat
Ford Explorer	1993–2002	Driver Seat
Mazda Navajo	1993–2002	Driver Seat
4 x 4 Ford Ranger	1995–2001	Driver Seat
Mazda B-Series Pick-up	1995–2001	Driver Seat
AWD Mercury Mountaineer	1997–2002	Driver Seat
MITSUBISHI		
3000 GT 4WD	1991–1994	Rear Center
Galant 4WD	1990–1992	Rear Center
Expo 4WD	1991–1993	Rear Center
Expo LVR 4WD	1991–1993	Rear Center
Eclipse 4WD	1991–1993	Rear Center
NISSAN		
Pathfinder 4x4	1996	Rear Center
SUBARU		
Subaru Legacy w/ 5MT AWD	1990–1995	Right Front
Subaru Impreza w/ 5MT AWD	1993–1996	Right Front

Vehicles without trunks, including SUVs, station wagons, and hatchbacks, do not contain a mercury switch in the rear of the vehicle.

Use Your Bucket

- Put date started on the provided universal waste label. Then put this label on the bucket.
- Utilize the provided MerDocForm.
- Keep the box your bucket was shipped in and the prepaid UPS label for returns.
- Do not put switches that are leaking mercury or non-automotive materials in the bucket.
- Return bucket no later than one year after the starting date or when it contains a maximum of 450 switches.

Return Your Bucket

- Two weeks before shipping your old bucket, call the Environmental Quality Company at 734.547.2511 for a new one.
- When ready to ship call UPS at 800.742.5877 and give them the Tracking Number on the UPS shipping label provided.
- Mail the three-part MerDocForm to:
 1. ADEQ—original form
 2. EQ—blue copy with bucket
 3. Keep—yellow copy
- Seal your bucket and place in the shipping box. Attach prepaid UPS label.

Arkansas law, A.C.A. § 8-9-600 *et seq.*, requires reducing mercury in the environment through removal and collection of mercury switches from end-of-life vehicles.

Questions? Call the ADEQ Mercury Switch Removal Program at 501.682.0594.

elvsolutions.org/

adeq.state.ar.us